
UMBRA@MOTORISATION

Somfy Oximo Battery RTS Motor

Radio Control








RTS controls explained










Smoove Wall Switch

Somfy Oximo motor wiring





Before You Start – Important Information





• Only the blind you want program can be connected to the power whilst programming. Disconnect all other blinds from the power to avoid interference.




- Do not reduce the motor cable to less than 30cm as this may cause communication problems between the remote control and the motor as the motor uses the copper core of the cable as a radio antenna.
- Do not connect the battery pack until you are ready to begin programming

Before You Start




Only one motor should be powered on at a time when setting limits or making any programming changes



Pairing The Remote

UMBRA®

Pairing the remote and setting turning direction







You now have 60 seconds to complete the steps on this page and pair the remote control



If you have a multi channel remote, select the channel you wish to pair the blind to




control until the blind shunts



Changing Turning Direction




Check and change the turning direction of the motor




Press and hold the button and observe the direction the blind travels.


It could travel in either direction depending on which side the motor is on




If the blind travels DOWN when you press the button you can skip the rest of this page and move straight on to setting the limits



If the blind travels UP when you press the button you need to change the turning direction








You can now check the turning direction is correct by pressing and holding EITHER the or button


The motor is still in programming mode so you have to press and hold to drive the blind


Setting Limits


UMBRA®


Set a top and bottom limit position






















Intermediate Stop Position


UMBRA®

bottom limit position

It is optional to set an intermediate stop position












Deleting the intermediate stop position










Adjusting Limits


UMBRA®


How to adjust any limit













Adding Remotes

UMBRA®


Copying a channel on one remote to a new remote













pair the blind to









Motor Reset

UMBRA®

Reset motor back to factory settings – wipes all remotes, limits and sensors



Begin with the power applied to the blind for at least 60 seconds



Turn off the power for 10 seconds



Turn on the power for 10 seconds

