




| Ref. No. | Description       | Qty. | Ref. No. | Description           | Qty. |
|----------|-------------------|------|----------|-----------------------|------|
| 01       | Pump Housing      | 1    | 26       | Yoke                  | 1    |
| 02       | 45° Elbow         | 1    | 27       | Piston Pin            | 1    |
| 03       | Oil Filter        | 1    | 28       | Yoke Pin              | 1    |
| 04       | O Ring            | 1    | 29       | E Ring                | 1    |
| 05       | Tie Rod           | 1    | 30       | Yoke Cover            | 1    |
| 06       | Head Base         | 1    | 31       | Handle                | 1    |
| 07       | O Ring            | 2    | 32       | Handle Grip           | 1    |
| 08       | Reservoir         | 1    | 33       | Steel Ball            | 2    |
| 09       | O Ring            | 3    | 34       | Inlet Ball Spring     | 2    |
| 10       | Air Release Screw | 1    | 35       | Steel Ball            | 2    |
| 11       | Tail Base         | 1    | 36       | Outlet Ball Spring    | 2    |
| 12       | O Ring            | 1    | 37       | Copper Washer         | 2    |
| 13       | Nut               | 1    | 38       | Valve Cover Screw     | 2    |
| 14       | Steel Ball        | 4    | 39       | Steel Ball            | 2    |
| 15       | Screw             | 3    | 40       | Spring End Cap        | 2    |
| 16       | O Ring            | 1    | 41       | LP Spring             | 1    |
| 17       | Nipple            | 1    | 42       | Overload Cover Screw  | 2    |
| 18       | Set Screw         | 1    | 43       | Cap                   | 2    |
| 19       | O Ring            | 1    | 44       | Spring                | 1    |
| 20       | Back-Up Ring      | 1    | 45       | Release Valve Packing | 1    |
| 21       | HP Piston         | 1    | 46       | Washer                | 1    |
| 22       | Snap Ring         | 1    | 47       | Release Nut           | 1    |
| 23       | O Ring            | 1    | 48       | Release Valve Screw   | 1    |
| 24       | Back-Up Ring      | 1    | 49       | Release Knob          | 1    |
| 25       | LP Piston         | 1    | 50       | Set Screw             | 1    |