



ITS8
(Square Drive) Hydraulic Torque Wrench
Torque Chart

Pressure (psi)	Pressure (bar)	Torque (Nm)
1,015	70	1,072
1,160	80	1,225
1,305	90	1,378
1,450	100	1,531
1,595	110	1,684
1,740	120	1,837
1,885	130	1,990
2,030	140	2,143
2,175	150	2,296
2,320	160	2,449
2,465	170	2,602
2,610	180	2,755
2,755	190	2,908
2,900	200	3,062
3,045	210	3,215
3,190	220	3,368
3,335	230	3,521
3,480	240	3,674
3,625	250	3,827
3,770	260	3,980
3,915	270	4,133
4,060	280	4,286
4,205	290	4,439
4,350	300	4,592
4,495	310	4,745
4,640	320	4,898
4,785	330	5,051
4,930	340	5,205
5,075	350	5,358
5,220	360	5,511
5,365	370	5,664
5,510	380	5,817
5,655	390	5,970
5,800	400	6,123
5,945	410	6,276
6,090	420	6,429
6,235	430	6,582
6,380	440	6,735
6,525	450	6,888
6,670	460	7,041
6,815	470	7,195
6,960	480	7,348
7,105	490	7,501
7,250	500	7,654
7,395	510	7,807
7,540	520	7,960
7,685	530	8,113
7,830	540	8,266
7,975	550	8,419
8,120	560	8,572
8,265	570	8,725
8,410	580	8,878
8,555	590	9,031
8,700	600	9,185
8,845	610	9,338
8,990	620	9,491
9,135	630	9,644
9,280	640	9,797
9,425	650	9,950
9,570	660	10,103
9,715	670	10,256
9,860	680	10,409
10,005	690	10,562
10,150	700	10,715

Values:	Formulae:	Example:
a) Torque Required b) Max. Torque Rating of the Hydraulic Torque Wrench	To calculate Pressure (bar): Pressure (bar) = (a x 700) / b	a = 3,827 Nm b = 10,715 Nm Pressure (bar) = (3,827 x 700) / 10,715 Pressure = 250 bar
a) Pressure (bar) b) Max. Torque Rating of the Hydraulic Torque Wrench	To calculate Torque Generated: Torque = (a / 700) x b	a = 500 bar b = 10,715 Nm Torque = (500 / 700) x 10,715 Torque = 7,654 Nm

values calculated in the above 'Torque' & 'Example' columns are approximate values