

Overview

iPhone 5 at a glance



Sleep/Wake Button




When you're not using the iPhone, you can lock it to turn off the display and save the battery




When you're not using the iPhone, you can lock it to turn off the display and save the battery

Lock iPhone: Press the Sleep/Wake Button



When iPhone is locked, nothing happens if you touch the screen. However, you can still receive calls, text messages and other updates. You can also:



When iPhone is locked, nothing happens if you touch the screen. However, you can still receive calls, text messages and other updates. You can also:

- Listen to Music
- Adjust the Volume
- Use the Center Button on your EarPods to take calls/listen to music

Unlocking the iPhone: Press the Sleep/Wake button or the Home button, then drag the slider

Unlocking the iPhone: Press the Sleep/Wake button or the Home button, then drag the slider

Turn iPhone on: Press and hold the Sleep/Wake button for a few seconds until the **s** logo appears

Unlocking the iPhone: Press the Sleep/Wake button or the Home button, then drag the slider

Turn iPhone on: Press and hold the Sleep/Wake button for a few seconds until the **s** logo appears

Turn iPhone off: Press and hold the Sleep/Wake button for a few seconds until the red slider appears, then drag the slider

Unlocking the iPhone: Press the Sleep/Wake button or the Home button, then drag the slider

Turn iPhone on: Press and hold the Sleep/Wake button for a few seconds until the **s** logo appears

Turn iPhone off: Press and hold the Sleep/Wake button for a few seconds until the red slider appears, then drag the slider

Access the Audio Controls: Double-click the Home Button

The Home Button



Going to the Home Screen: Press the Home Button

Going to the Home Screen: Press the Home Button


Displaying recently used apps: Double-click the Home Button. The multitasking bar appears at the bottom of the screen, showing the most recently used apps. Swipe the bar left to see more apps.

Going to the Home Screen: Press the Home Button


Displaying recently used apps: Double-click the Home Button. The multitasking bar appears at the bottom of the screen, showing the most recently used apps. Swipe the bar left to see more apps.

Using Siri or other Voice Control: Press and hold the Home Button

Volume Controls




While you're on the phone or listening to songs, movies, or other media, the buttons on the side of iPhone adjust the audio volume. Otherwise, the buttons control the volume for the ringer, alerts, and other sound effects.



The iPhone Volume Controls can be manipulated in a few different ways:

Lock the ringer and alerts volume: Go to Settings > Sounds and turn off "Change with Buttons."




The iPhone Volume Controls can be manipulated in a few different ways:

Lock the ringer and alerts volume: Go to Settings > Sounds and turn off "Change with Buttons."

Limit the volume for music and video: Go to Settings > Music > Volume Limit

Ring/Silent Switch



Flip the Ring/Silent Switch to put the iPhone in ring mode or silent mode

In ring mode, iPhone plays all sounds. In silent mode, iPhone doesn't ring or play alerts and other sound effects

Status Icons

	Cell Signal: Shows whether you're in range of the cellular network and can make and receive calls. The more bars, the stronger the signal. If there's no signal, the bars are replaced with "No service."
+	Airplane Mode: Shows that airplane mode is on—you cannot use the phone, access the Internet, or use Bluetooth® devices. Non-wireless features are available.
LTE	LTE: Shows that your carrier's LTE network is available, and iPhone can connect to the Internet over that network.
4G	UMTS: Shows that your carrier's 4G UMTS (GSM) network is available, and iPhone can connect to the Internet over that network.
3 G	UMTS/EV-DO: Shows that your carrier's 3G UMTS (GSM) or EV-DO (CDMA) network is available, and iPhone can connect to the Internet over that network.
E	EDGE: Shows that your carrier's EDGE (GSM) network is available, and iPhone can connect to the Internet over that network.

0	GPRS/1xRTT: Shows that your carrier's GPRS (GSM) or 1xRTT (CDMA) network is available, and iPhone can connect to the Internet over that network.
?	Wi-Fi: Shows that iPhone is connected to the Internet over a Wi-Fi network. The more bars, the stronger the connection.
	Do Not Disturb: Shows that "Do Not Disturb" is turned on.
<u>ල</u>	Personal Hotspot: Shows that iPhone is connected to another iPhone providing a Personal Hotspot.
Ð	Syncing: Shows that iPhone is syncing with iTunes.
>1×	Network Activity: Shows network activity. Some third-party apps may also use the icon to show an active process.

(->	Call Forwarding: Shows that Call Forwarding is set up on iPhone.
VPN	VPN: Shows that you're connected to a network using VPN.
	Lock: Shows that iPhone is locked.
	TTY: Shows that iPhone is set to work with a TTY (Text Telephone) machine.
	Play: Shows that a song, audiobook, or podcast is playing.
@	Portrait orientation lock: Shows that the iPhone screen is locked in portrait orientation.

•	Alarm: Shows that an alarm is set.
1	Location Services: Shows that an item is using Location Services.
*	Bluetooth: Blue or white icon - Bluetooth is on and paired with a device. Gray icon -Bluetooth is on and paired with a device, but the device is out of range or turned off.
	Bluetooth battery: Shows the battery level of a supported paired Bluetooth device.
	Battery: Shows battery level or charging status.

